

APPLICATION INSTRUCTIONS

TOPOIL - CLEAR, NATURAL, ACACIA - 3056, 3025, 3026

BY HAND WITH A CLOTH/RAG

Apply three thin coats with a lint-free cloth.

1. Scrub product into wood using cloth in a circular or figure 8 pattern
2. Allow roughly 15-minutes for oils to penetrate
3. Working with the grain, remove all excess product from surface
4. Allow 8-10 hours drying time before recoating
5. Apply second and third coats following previous steps



WARNING: Cloths saturated with product are a spontaneous combustion hazard and should be left out unfolded until dried, prior to disposal or preferably stored in a proper fireproof container

BY HAND WITH A BRUSH

Apply two thin coats with an Osmo Natural Bristle Brush or similar brush.

1. With a brush, work product into wood working in all directions, ensuring a thin application
2. Allow roughly 15-minutes for oils to penetrate
3. Working the brush with the grain, evenly distribute all product on surface and remove excess
4. There should be no visible high-build or film – if this is observed, product is over applied
5. Allow 8-10 hours drying time before recoating
6. Apply second coat following above procedure
7. Clean brushes using Osmo Brush Cleaner and Thinner or Turpentine

Tinting: Osmo Wood Wax Finish can also be used to lightly tint TopOil 3056 up to a ratio of 10:1. Do not exceed a ratio of 10 parts TopOil 3056 to 1 part Wood Wax Finish.